

## **Monitor/Maintain Alley Scrapers**

**Things needed:** grease, water hose

- Lubricate bearing housing (daily)
- Spray alley scrapers clean (daily)
- Grease drive unit bearing and corner wheels (weekly)
- Lubricate threaded rod and upper bearings (weekly)
- Operate gate valves (weekly)
- Inspect chain/rope/cable tension (monthly)
- Check and adjust scraper blades (monthly)